How to apply the Back Panel Protecter Film



*Please do not forget to peel this film off as a final step.

protective film using [removal sticker].

How to apply the Camera Lens Film

①Use a soft cloth and gently clean the camera lens.

②Peel off one transparent film for camera lens from the backing film and leave the film half peeled off.

Apply the [B: Camera Lens Auxiliary sheet] to about half of the film for camera lens, and peel it off the backing film.

*Please note: If you put the auxiliary sheet on the film entirely not partially, it may become difficult to apply.



③Place the film on the camera lens, which has now been detached from the backing film.

Once you have decided on its position, use one finger to place the film on the camera lens, apply it firmly to the camera lens and then you are ready to go.



What to do in the following cases

If air bubbles are formed:

OBigger bubbles can be removed by pushing the film outward with your finger.

*Please rest assured that small air bubbles without any trapped dust or dirt will naturally disappear within one or two days.

○If there is trapped dust or dirt, use adhesive tape to peel off the film up to the dirty area, and use the adhesive surface of the tape to take it away.

You can also clean the dirty area of the film with water(if your device is not waterproof, make sure that any water drips are dried off before affixing the film again.)





If the film is not affixed in the right place:

- (1) Use adhesive tape to temporarily peel off the film.
- (2) Hold the edge of the film and affix it again onto your device. Take care not to touch the adhesive surface of the film with your fingers.

How to peel off the film:

- Take a long strip of strong adhesive tape and affix it to one of the four corners of the film.
- (2) Lift off the film gently by pulling on the adhesive tape horizontally, parallel to the film. Once air goes into the edge of the film, it should come off easily.

Please check our website explaining how to apply a protector film with pictures.

You can also download pdf files of the manual. http://www.asdec.co.jp/product/how_fi_eng.html ⇒





